Lebanon Phone Center & Alarm, Inc.

Your Communications & Security Specialists

219 W. Commercial Lebanon, M. 65536 Tel. 417-532-9819 Fax: 417-588-4258

Attendant Features

8.6 System Telephone Naming

You can assign a name that is either a personal name or a group name to each system telephone. This name can be up to seven letters in length and will show up in the user's display and/or in the called party's display. You can compose a valid name from any alpha-numeric character; however, the first character of a display name must be an alphabetic character. Typical names could be SRVC, MKTG 1, and K SMITH. When appropriate programming action has been taken by the installer, a second line showing the personal intercom number of the calling station is also displayed.

Name the system telephones as follows:

- 1. USE letter code table to compose names for all telephones requiring them (up to seven letters per name are allowed)
- 2. PRESS INTERCOM.
- 3. DIAL *#0*53.
- 4. SELECT telephone to be named by dialing the extension number DIAL number plus # if extension number is less than 4-digits).
- 5. DIAL # to clear any current entry.
- 6. DIAL 2-digit codes that correspond to letters in name (station names must begin with a letter).
- 7. DIAL # to save name or save cleared name.
- 8. REPEAT steps 4 through 7 until all telephones are named.
- 9. PRESS SPEAKER to end.

Letter Code Table for LCD Messages							
Character	Code	Character	Code	Character	Code	Character	Code
A	21	S	73	j	54	SPACE	12
В	22	T	81	k	55	;	17
C	23	U	82	1	56	/	18
D	31	V	83	m	64	"	19
E	32	W	91	n	65		27
F	33	X	92	0	66	,	28
G	41	Y	93	p	74	:	29
Н	42	Z	13	q	14	1	01
I	43	a	24	r	75	2	02
J	51	b	25	S	76	3	03
K	52	С	26	t	84	4	04
L	53	d	34	u	85	5	05
M	61	e	35	v	86	6	06
N	62	f	36	w	94	7	07
O	63	g	44	X	95	8	08
P	71	h	45	у	96	9	09
Q	11	i	46	Z	16	0	00
R	72						