

SBX CALL FORWARDING

1 > Press [SPEAKER] button.

2 > Press [DND/FWD] button.

Follow-me Forward

- 0 Follow-me Forward *Retrieve your station calls From another Station*
Dial station number to forward, enter security code (voicemail access code) then dial #

Unconditional, Busy, No Answer, Busy/No Answer Forward

- 1 Unconditional *Forwards all calls, immediate*
- 2 Busy *Only forwards when you are busy on phone*
- 3 No answer *Forwards when you don't answer phone*
- 4 Busy/No answer *Forwards when your phone is busy or no answer*

Enter forward destination (STA/HUNT/VMIB).

STA: station number, 100-132.

HUNT: Hunt group, 620-629.

VMIB: # (Forward to Voicemail Box)

Unconditional, No Answer Off-net Forward with speed bin *(forward to programmed speed dial #)*

IMPORTANT: *Must have positive disconnect signal from Phone Company on lines*

- 5 Unconditional
- 6 No answer

Enter speed bin number.

(Station speed bin :000-099, system speed bin:2000-2499)

Unconditional, No Answer Off-net Forward telephone number *(allows you to enter # forwarding to)*

IMPORTANT: *Must have positive disconnect signal from Phone Company on lines*

- 8 Unconditional
- 9 No answer

Enter telephone number. Press (HOLD/SAVE)

To Cancel Press (DND/FWD) button